

MIRAGE UNLIMITED JEEP @GMAIL.COM

MIRAGE UNLIMITED MIRROR INSTALL DIRECTIONS (MU0100) - (MU0104-QM) - (MU0100-QM) (FOR JK NON-ELECTRIC MIRRORS)

1, REMOVE FACTORY MIRROR HEAD BY BACKING OUT THE BOLT THAT HOLDS THE MIRROR HEAD TO THE FACTORY BRACKET (THREE TURNS). TAP THE BOLT WITH A HAMMER TO LOOSEN THE MIRROR HEAD FROM THE BRACKET. THEN REMOVE THE FACTORY MOUNTING BRACKET FROM THE DOOR (Two bolts on the inside of the door). IF YOU HAVE ELECTRIC MIRRORS YOU WILL NEED TO REMOVE THE TRIM PANEL AND UNPLUG AT THE CONNECTION.

**2. INSTALL THE MIRAGE MOUNT TO THE DOOR WITH TWO BOLTS SUPPLIED. THEN MOUNT THE MIRROR ARM TO THE MIRAGE DOOR BRACKET.
(Be sure to start the bolt threads correctly by hand so as not to cross thread)**

3. NOW INSTALL THE QUADRATEC MIRROR HEAD OR YOUR FACTORY MIRROR HEAD TO THE MIRAGE MOUNT WITH BOLT SUPPLIED. (If you have electric mirrors you will have to replace them with non-electric Quadratec or factory mirrors. You can use your electric mirrors if you snip / remove the wires. (THAT'S IF YOU SO DESIRE!)

4. TO INSTALL THE MIRAGE MOUNT AT THE WINDSHIELD PILLAR, (KNOWN AS THE "A" PILLAR) REMOVE TWO FACTORY BOLTS. PLACE THE MIRAGE MOUNT AT THE PILLAR AND REINSTALL THE FACTORY BOLTS OR BOLTS SUPPLIED.