



JL HD MOLLE TAILGATE PANEL

HEAVY DUTY MOLLE MODULAR STORAGE SYSTEM

The HD MOLLE Tailgate Panel is secured to the tailgate trim panel with 10 screws. To begin installation, center the HD MOLLE Panel on the tailgate trim panel as shown at right. The grommets in the top edge of the panel should be positioned along the top of the panel so the screws will go into the top edge of the trim panel. Starting at one end of the HD Molle panel, drill a 1/16" hole through the first grommet and install a screw, tightening the screw snugly. Work your way to the other side of the panel, stretching the panel before drilling each successive hole. Once the top has been secured with all 5 screws, do the same along the bottom, starting at one end and again stretching the panel before drilling each screw hole.

INSTALLATION INSTRUCTIONS



JL HD MOLLE TAILGATE PANEL

HEAVY DUTY MOLLE MODULAR STORAGE SYSTEM

CARE INSTRUCTIONS

The SHERPA HD MOLLE Tailgate Panel is made from heavy cotton canvas fabric and leather and is designed to give years of service on the road and trail. Canvas is very easy to clean and handle - a soft and dry bristled brush can be used to remove any loose dust or dirt. If the canvas needs further cleaning, mix clean water and a small amount of mild detergent and use a damp towel or bristled brush dipped in the solution and scrub or rub the dirty areas gently. Lightly spray the canvas area with water to remove the soap residue and dry with a towel. To keep the SHERPA HD MOLLE Tailgate Panel looking new longer, we recommend treating the fabric with Scotchgard Auto Fabric & Carpet Protector. Scotchgard provides excellent resistance to water, oil and stains and it doesn't change the look and feel of the fabric, so the fabric stays soft and colors stay true. Scotchgard comes in an easy-to-use spray bottle.



Note: Do not Dry-Clean, bleach or put in the dryer as these may potentially discolor the canvas or leather.